## 24micron PHOTOMETRY Flats as a Function of Scan Mirror Position

Almudena Alonso-Herrero, Steward Observatory Last revision: Oct 2, 2003

## ABSTRACT

Observations obtained in 24micron PHOTOMETRY mode reveal the presence of the so-called "Dark Spots" which are regions of a few pixels approximately 20% dimmer than the surrounding pixels. These "Dark Spots" move with sources for scan mirror positions, and thus to remove them from 24micron observations we need to construct 24micron Flatfields for each of the scan mirror positions used during the observation. We use the 24micron flatfields observed in Campaigns D2 and E to construct flatfields at the 7 scan mirror positions used by SMALL FIELD PHOTOMETRY, that is, CSM\_PRED=1864.5, 1886., 1907.5, 1929., 2106.5, 2128., and 2149.5. Ratios of flatfields constructed with flats with increasing (or decreasing) scan mirror angle show how these "Dark Spots" move in terms of the scan mirror position. Apart from the already detected three bright "Dark Spots" in the upper left corner, we can see that there is a number of more diffuse and fainter ones at other positions across the 24micron array. Clearly, it is essential that at 24micron we flatfield each observed DCE with a 24micron flatfield with matching scan mirror position.

AOR keys: 6764032, 6764288, 6770176, 6770432

## DESCRIPTION

Observations obtained in 24micron PHOTOMETRY mode reveal the presence of the so-called "Dark Spots" approximately 20% dimmer than the surrounding pixels (see MIPS Campaign D2 Anomaly Report). Since they move analogously to sources for scan mirror moves, but do not move when the telescope nods, to remove them from observations we will need to construct 24micron Flatfields for those scan mirror positions. These "Dark Spots" are attributed to debris on the pick-off mirror.

We use the 24micron PHOTOMETRY flatfields observed in campaigns D2 and E to construct 24micron flatfields as a function of the Scan Mirror Position, that is, we use all the observations available of MIPS-917. The MIPS-917 flatfields are observed in PHOTOMETRY SMALL FIELD. Each MIPS-917 observation consists of a 4 point dither map (1 cycle, using the cluster mode) with 3 second DCEs, providing a total of 64DCEs. The predicted scan mirror positions (keyword: **CSM\_PRED**) as a function of the DCE number are:

DCE CSM PRED 1929. - BIAS BOOST FRAME (not used) [1] [2] 2149.5 [3] 1907.5 [4] 2128. [5] 1886. [6] 2106.5 1864.5 [7] [8] 1929. [9] 1929. - BIAS BOOST FRAME (not used) [10] 2149.5 [11] 1907.5 [12] 2128. [13] 1886. [14] 2106.5 [15] 1864.5 [16] 1929.

For each of the 7 scan mirror positions used in the 24micron SMALL FIELD PHOTOMETRY MODE we construct a flatfield using the *imcombine* and *bscale* tasks in IRAF, so each flatfield is the result of median combining 32DCEs. Statistics on the normalized flatfields provides the following:

IMAGE	NPIX	MEAN	STDDEV	MIN	MAX
flat_CSMeq1865_norm.fits	16362	1.006	0.05381	0.8285	1.238
flat_CSMeq1886_norm.fits	16362	1.007	0.05375	0.8282	1.234
flat_CSMeq1908_norm.fits	16362	1.005	0.0534	0.8273	1.23
flat_CSMeq1929_norm.fits	16362	1.005	0.05354	0.8277	1.238
flat_CSMeq2107_norm.fits	16362	1.005	0.05343	0.7972	1.231
flat_CSMeq2128_norm.fits	16362	1.003	0.05337	0.7677	1.229
flat_CSMeq2149_norm.fits	16362	1.007	0.05338	0.7986	1.233


The standard deviation of the flatfiels constructed for different scan mirror positions is similar to that of the flatfields constructed combining 64 or 128DCEs (i.e., see Analysis report of MIPS-917 in D2 and E).

To assess the qualitative differences of 24micron flatfields observed at different scan mirror positions we do ratios flatfields with CSM\_PRED values in a sequential way, that is,

ratio1=flat\_CSMeq1865\_norm.fits / flat\_CSMeq1886\_norm.fits ratio2=flat\_CSMeq1886\_norm.fits / flat\_CSMeq1908\_norm.fits ratio3=flat\_CSMeq1908\_norm.fits / flat\_CSMeq1929\_norm.fits ratio4=flat\_CSMeq1929\_norm.fits / flat\_CSMeq2107\_norm.fits ratio5=flat\_CSMeq2107\_norm.fits / flat\_CSMeq2128\_norm.fits ratio6=flat\_CSMeq2128\_norm.fits / flat\_CSMeq2149\_norm.fits ratio7=flat\_CSMeq2149\_norm.fits / flat\_CSMeq1865\_norm.fits

The ratios of 24micron flatfields with different scan mirror positions are shown in Figures 1 and 2. The ratios of flatfields observed with increasing scan mirror position clearly show how the 24micron 'Dark Spots' move with changing mirror position. Apart from the bright three "Dark Spots" in the upper left corner already detected, we can see that there is a number of more diffuse and fainter ones at other positions across the 24micron array.

Clearly, it is essential that at 24micron we flatfield each observed DCE with a 24micron flatfield matching the observed scan mirror position.



**Figure1.** We show from ratios of flatfields constructed for different scan mirror positions (those used in SMALL FIELD PHOTOMETRY). From the upper left corner and clockwise we show ratio1, ratio2, ratio4 and ratio3 with display levels z1=0.97 and z2=1.01.





Figure2. As Figure1 but for ratio5 (upper left), ratio6 (upper right) and ratio7 (lower left).

For LARGE FIELD PHOTOMETRY MODE the CSM\_PRED values are:

2007.12, 2021.5, 1999.875, 2014.25, 1992.625

Flatfields for these values of CSM\_PRED could be interpolated from the 24micron flatfields observed in SMALL FIELD PHOTOMETRY MODE.

In Figure3 we show the results of flatfielding data with one single flatfield (upper panel) and using different flatfields constructed as a function of different scan mirror positions (lower panel).



**Figure3.** The upper panel is a star observation flatfielded using one single flatfield. The lower panel shows the same observation where each DCE was flatfield with a matching CSM\_PRED flatfield. The two images are shown with the same display values. The mosaics were produced with the IRAF task imcombine!